

STILLMADE

INSTALLATION INSTRUCTION

Profile Console

**YOU'LL
NEED**

Pencil

Level

Tape Measure

Flathead Screwdriver

Power Drill - 1/8" drill bit, 1/2" drill bit

**WHAT'S
PROVIDED**

Wooden Cleat

Profile Console

CABINET INSTALLATION

Determine desired height of the console. We recommend 31"-34" off the floor.

Using a level and tape measures, position the bottom of the wooden cleat 4" below the desired height of the console.

Using a 1/8" drill bit, drill through the holes on the wooden cleat (These instructions assume a 5/8" gypsum wall surface on aluminum or wood studs).

If you drill through a wood or metal stud, you can screw the wooden cleat directly into the wall with a 2" #8 flat head screw.

Place wooden cleat back on the wall and line up the holes with the anchors you just installed and screw in cleat with provided screws.

Place console a few inches above the cleat and let the console slide down the wall until it fits into place on the cleat. Give the top of the console a few light pounds with the soft side of a closed fist so the console sits firmly in place.

DOOR INSTALLATION

Determine the bottom of the doors by locating the plastic rollers on the mechanisms, which are on the backside of the door.

Place the tabs behind the rollers into the innermost groove on the console.

Line up the top of the door with corresponding groove and using either your finger or a flat head screw driver, push the tab from the roller mechanism up into the groove. Repeat for the second door in the outermost groove.

* Carefully look to ensure the top tabs are fully in the groove otherwise the doors are susceptible to fall from the console.

INSTALLATION INSTRUCTION

Profile Console